


AUTO-PURGER PM AND REBUILD KIT GUIDE



AUTO-PURGER PARTS & KITS

AP PREVENTATIVE MAINTENANCE KIT

(Use Parts Discount)

Item	Description	Qty
20-2400	AP Preventative Maintenance Kit for AP08, AP16, AP24, AP01, and APC	1
	<i>Kit consists of the following:</i>	
20-1183	Check Valve, 1 PSID with 1/32" Orifice	1
20-1184	Check Valve, 30 PSID	1
20-1185	Check Valve, 225 PSID	1
20-1279	2 AMP Fuse for AUTO-PURGER	1
20-1281	5 AMP Fuse for AUTO-PURGER	1
20-1737	Metering Strainer Basket Kit	1
70-1059	Solenoid Tube/Plunger Kit	6
78-0016	Bottom Cap Gasket for ST050	3



AP REBUILD KIT

(Use Parts Discount)

Item	Description	Qty
20-2401	AP Rebuild Kit for AP08, AP16, AP24, AP01, and APC	1
	<i>Kit consists of the following:</i>	
20-2400	AP Preventative Maintenance Kit	1
20-1307	Thermostat	1
20-2310	Insulation Patch for Thermostat	1
HS8A/1	Foul Gas Solenoid Valve	1
20-1208	Knob for Rotor Switch	1
20-1746	Clear Tube for Bubbler	1
20-1379	O-Rings for Clear Tube for Bubbler	4
20-1713	Nylon Elbow Tube	2
20-2005	Straight Fitting, Nylon MPT	1
20-1395	Straight Fitting, Nylon FPT	1
20-1242	3 Feet of Tubing, Nylon 3/8"	1
35-0035	Pressure Gauge	1
	<i>AP Rebuild Kit does not include:</i>	
20-1179	Level Master Control Valve (115v)	1

SUPPLEMENTAL KITS

(Use Technical Equipment Discount)

Item	Description	Qty
APLK	Purging Log Kit	1
APPLT	Beacon Pilot Light for AP (4 Green, 2 Amber)	1
APMPLT	Beacon Pilot Light for APM (2 Green, 2 Amber)	1