


Remote Alarm Light and Horn Unit TO WATCHMAN

NOTE;

- 1) Remove TB1 And TB2 plugs before attaching the wires.
- 2) Ensure TB1 and TB2 wires are secure before plugging them into the WATCHMAN.
- 3) Ensure power is off before plugging in TB1 and/or TB2.
- 4) Verify all wiring before applying power.




From RAL-HU "BLK" to WATCHMAN
TB2 "G" Black wire

From RAL-HU "RED" to WATCHMAN
TB2 "+" RED wire

From RAL-HU "GRN" to WATCHMAN
TB2 "G" Green wire

From RAL-HU "WHT" to WATCHMAN
TB2 "S1" White wire



Watchman TB1 "S" is the 4 to 20mA signal
output